

510mm

HY055EC  
Cutting template

--- Carcass Outline

— Cutting area

— Outer Frame outline

--- Timber support

Timber Support

Timber Support

775mm

1. Place the template on the wall where the mirror cabinet will be located.
  2. Mark the cutting area, marked in red.
  3. Create the cavity in the wall, making sure to place timber in the designated support areas.
  4. Make all electrical connections and mount the cabinet to the wall.
  5. Secure the cabinet to the timber with the screws provided.
- For detailed mounting guidelines, refer to product instructions.**

saneux

BATHROOMS FOR LIFE  
LONDON

Timber Support