

Aftercare Instructions

When cleaning with chlorine-based cleaners to clean the pan bowl, ensure that these do not come into contact with the seat. Keep the seat and cover in an upright position during cleaning to avoid discolouration of surfaces or rusting of metal parts.

Customer Services

t: +44(0)208 686 5100
e: technical@saneux.com

4 Imperial Way
Croydon CR0 4RR

www.saneux.com



s a n e u x

AUSTEN

50074

Back to Wall Pan

INSTALLATION INSTRUCTIONS



Fixing the pan

1. Make sure all the components are present.
2. With the pan in the desired location, mark the position of the holes on the floor. Measure the ceramic thickness of the pan and mark the approximate location of the floor fixings. Drill a hole on the ground and locate the plugs so that they are flush with the ground surface. Tighten the floor fixings.
3. With the pan on the desired location, check that the back of the pan fully meets the wall. Remove the pan and further tighten the floor fixings. Return the pan to the desired location paying attention that the pipe fittings are connected with the tubes and secure the screws to the floor fixings through the holes on the sides of the pan. Place the cover caps on the side holes.
4. Add sealant around the back of the pan, creating a watertight seal between the pan and the wall.
5. Install the seat according to the fitting instructions included in the seat's box.

